



NOTES:

- A. VISIT [GCPAT.COM](http://GCPAT.COM) FOR THE MOST CURRENT DETAILS AND INSTALLATION VIDEO
- B. REFER TO PRODUCT DATA SHEETS ON WEB SITE FOR FURTHER INFORMATION
- C. THE DRIP EDGE IS INSTALLED OVER THE GCP UNDERLAYMENT
- D. INSTALL GCP UNDERLAYMENT TO FORM WATER-SHEDDING LAPS
- E. REPAIR ALL HOLES LEFT FROM REMOVAL OF TOE BOARDS, ROOF JACKS, ETC.



**EAVE OPTION-1  
WITHOUT DRIP EDGE STRIPPED-IN  
GRACE ICE & WATER SHIELD®**

**Drawing: IWSDET-101**

**Scale: Not to scale**

**Effective Date: 01/22/2018**

**Supersedes: 05/16/2006**