



- NOTES: A) USE SEAM ROLLER TO ENSURE PROPER SEAL TO THE INVERTED PREPRUFE CJ TAPE
 B) DO NOT POSITION INJECTION PORT ASSEMBLY DIRECTLY OVER THE END LAP
 C) IF HYDRODUCT IS USED AS PART OF THE DRAINAGE SYSTEM, 6 MIL, 1.5 mm POLY IS REQUIRED BETWEEN THE HYDRODUCT AND THE PREPRUFE SCS MEMBRANE



END LAP
PREPRUFE® SCS
WATERPROOFING SYSTEM FOR SHOTCRETE

DRAWING: SCS 002

SCALE: Not to scale

EFFECTIVE DATE: 08/1/2016

SUPERSEDES: 03172014