



NOTES:

- A. VISIT GRACECONSTRUCTION.COM FOR THE MOST CURRENT DETAILS, INSTALLATION VIDEO AND PRODUCT DATA SHEETS
- B. RIPCORD CAN BE REMOVED FROM GRACE VYCOR FLASHING FOR EASE OF INSTALLATION
- C. INSTALL GRACE VYCOR FLASHING AND VYCOR enV-S TO FORM WATER-SHEDDING LAPS
- D. INSTALL VYCOR enV-S VERTICALLY OR HORIZONTALLY TO FORM WATER SHEDDING LAPS
- E. FOR SILL PAN DEPTHS GREATER THAN 6 INCHES, A SLOPED SILL IS REQUIRED IN ACCORDANCE WITH ASTM E 2112
- F. A BACK DAM CAN BE ACCOMPLISHED USING A WOODEN FURRING STRIP OR BY FOLDING THE GRACE VYCOR FLASHING ADHESIVE LAYER ONTO ITSELF
- G. LEAVE RELEASE PAPER ON LOWER HALF OF GRACE VYCOR FLASHING SILL FLASHING FOR FUTURE TIE-IN TO VINYL SIDING
- H. EXTEND GRACE VYCOR FLASHING OVER NAILING FLANGE OF THE LAST COMPLETE COURSE OF SIDING PANEL AND TRIM GRACE VYCOR FLASHING TO PROTECT FROM PERMANENT EXPOSURE TO UV
- I. LEAVE RELEASE PAPER ON OR OTHER BOND BREAKER BETWEEN GRACE VYCOR FLASHING AND VINYL
- J. INSTALL GRACE VYCOR FLASHING AROUND REMAINING WINDOW UNIT PER GRACE WINDOW DETAILS (VCRDET-100 TO 111)
- K. DETAIL ALSO RELEVANT FOR ALL GRACE VYCOR FLASHINGS

GRACE
Construction Products
www.graceconstruction.com
toll free 866-333-3726

**TIE-IN WITH VINYL SIDING
AT WINDOW SILL
GRACE VYCOR® SELF-ADHERED FLASHING**

Drawing: VCRENVS-107

Scale: Not to scale

Effective Date: 05/01/14

Supersedes: NEW