



NOTES:

- A. VISIT GRACECONSTRUCTION.COM FOR THE MOST CURRENT DETAILS, INSTALLATION VIDEO AND PRODUCT DATA SHEETS
- B. RIPCORD CAN BE REMOVED FROM GRACE VYCOR PLUS FOR EASE OF INSTALLATION
- C. INSTALL GRACE VYCOR PLUS AND WEATHER RESISTIVE BARRIER TO FORM WATER-SHEDDING LAPS
- D. FOR SILL PAN DEPTHS GREATER THAN 6 INCHES, A SLOPED SILL IS REQUIRED IN ACCORDANCE WITH ASTM E 2112
- E. A BACK DAM CAN BE ACCOMPLISHED USING A WOODEN FURRING STRIP OR BY FOLDING THE GRACE VYCOR PLUS ADHESIVE LAYER ONTO ITSELF
- F. LEAVE RELEASE PAPER ON LOWER HALF OF GRACE VYCOR PLUS SILL FLASHING FOR FUTURE TIE-IN TO VINYL SIDING
- G. EXTEND GRACE VYCOR PLUS OVER NAILING FLANGE OF THE LAST COMPLETE COURSE OF SIDING PANEL AND TRIM GRACE VYCOR PLUS TO PROTECT FROM PERMANENT EXPOSURE TO UV
- H. LEAVE RELEASE PAPER ON OR OTHER BOND BREAKER BETWEEN GRACE VYCOR PLUS AND VINYL
- I. INSTALL GRACE VYCOR PLUS AROUND REMAINING WINDOW UNIT PER GRACE WINDOW DETAILS (VCRDET-100 TO 111)
- J. DETAIL ALSO RELEVANT FOR ALL GRACE VYCOR FLASHINGS
- K. REFER TO LOCAL BUILDING CODE REQUIREMENTS FOR WEATHER RESISTIVE BARRIER